

## UPS SNMP and WEB LAN Card

1. The UPS LAN Card is suitable for all Vault, Athlon and Track Series UPS.
2. In order to use the LAN Card, the UPS must have a Smart Slot installed.
3. The LAN Card comes with built-in "web-enabling" software which allows the card to communicate using TCP/IP protocol (internet protocol). This "web-enabling" software allows the user to access, monitor and/or control the UPS via a web browser using an IP address assigned to the UPS.
4. Alternately, the user can access, monitor and/or control the UPS via a local area or corporate network as long as the card is set up accordingly.
5. If the UPS is connected to a computer via the RS232 Port, (i.e. without the LAN Card), then the "web-enabling" software will need to be installed separately in order to access, monitor and/or control the UPS over a network or via the internet using a web browser.
6. A photo of the LAN card is shown below:

